

# R8 Tooling

## End Mill Adaptors

Fig 1





Fig 2



Ordering No.	Stock	Style	Capacity d	D	L	L1	L2	L3
R8-EM06-026	•	1	6	25	26	18	-	40
R8-EM10-026	•		10	35	26	20	-	45
R8-EM12-031	•		12	42	31	22,5	-	50
R8-EM16-037	•		16	48	37	24	-	53
R8-EM20-040	•		20	52	40	25	-	55
R8-EM25-075	•	2	25	65	75	24	49	60
R8-EMI 1000-075	○		25,4 (1")	65	75	24	49	60


## Spare parts

Sidelock Screws



See page  
139

## Face Mill/Shell Mill Adaptors



SM16 and SM22 supplied with Caphead Screw

Ordering No.	Stock	d	L	s	D	K	T
R8-SM16-015	•	16	15	6	44	8	M8
R8-SM22-015	•	22	15	10	54	10	M10
R8-SM27-015	•	27	15	12	60	12	M12
R8-SM32-017	•	32	17	16	78	14	M16

## Spare parts

Wrenches



See page  
131

Retaining Screws



See page  
140

Drivekeys



See page  
140